

The RETRO-HPL Series

Energy Efficient LED Light Engine

Designed to retrofit directly into existing Source 4® PAR fixtures.

The RETRO-HPL is a CSA listed, Energy Star 2.0 retrofit kit that rapidly transforms existing inefficient HPL incandescent fixtures into energy efficient LED fixtures. Our patented technology allows the fixture to smoothly dim from 0-100% utilizing existing dimming technology. Our LED technology creates even fields and delivers consistent color.



CAREFULLY READ THE INSTALLATION INSTRUCTIONS BEFORE USING THIS FIXTURE.

This Retrofit is intended for the Source 4® PAR. This unit replaces the lamp inside the PAR fixture while providing new optics for your various light output needs. This retrofit is compatible with a Source 4® PARNel and details for installation will be covered in another future installation guide. If you have questions about this please contact Canto USA for assistance.

WARNING: DO NOT USE ETC® LENSES OR GEL FRAME IN THIS UNIT. If the use of gel is required there is a magnetic gel frame that can be purchased separately. Accessories, like open barn doors and top hats, that do not obstruct air flow are acceptable.

The instructions given here ensure safe usage of this product. Failure to comply with the installation, operation, maintenance and safety procedures mentioned in this manual as well as those generally applicable to lighting equipment, may cause the fixture not to perform as expected.

CantoUSA accepts no liability for direct, indirect, incidental, special, or consequential damages resulting from failure to follow the installation, operating, maintenance and safety procedures described in this manual. These limitations extend to damages for personal injury, property damage, loss of operation, loss of profits, loss of product or loss of time, whether incurred by the customer, the customer's employees, or third-party vendors or users.

Apart from the instructions given in this manual, all relevant safety and health standards of the appropriate local city and state electrical / safety directives must be complied with.

<u>PLEASE SEE OUR GENERAL TERMS OF SALE AND WARRANTY CARD PROVIDED WITH YOUR NEW EQUIPMENT OR EMAIL</u> US FOR A COPY AT ANY TIME.









BEFORE YOU GET STARTED, PLEASE READ THESE INSTALLATION INSTRUCTIONS COMPLETELY.

WHAT'S INCLUDED IN THE BOX (HOUSE LIGHT VERSION) THIS VERSION COMES WITH THE REFLECTOR CHOSEN AT TIME OF ORDER ALREADY MOUNTED.



RETRO-HPL Unit

RETRO-HPL Lamp Adapter

WHAT'S INCLUDED IN THE BOX (THEATRICAL VERSION)

THIS VERSION COMES WITH THE REFLECTORS SEPARATE FROM THE UNIT AND ARE MOUNTED USING THE MAGNETIC HOLDER. THIS ALLOWS THE REFLECTORS TO BE EASILY CHANGED AT ANY TIME.







RETRO-HPL Lamp Adapter



Number of Lenses Ordered



Magnetic Retaining Ring









INSTALLATION INSTRUCTIONS FOR THE RETRO-HPL:



STEP 1

Upon opening the boxes, please make sure the RETRO-HPL units are undamaged and in good physical condition.



STEP 2

Unplug the Source 4® fixture from its power source and allow the unit to cool if it is hot.



STEP 3

Remove the rear cap and remove the lamp. Recycle or discard the lamp per local requirements, codes, or customs. Inspect the lamp cap to make sure there is no damage and that existing wiring and connectors are in good condition. Repair or replace if damaged.



STEP 4

Remove the lens form the front of the Source 4 fixture. YOU WILL NOT NEED THESE AGAIN.



STEP 5

Turn the existing inside lens ring of the Source 4® PAR so the 2 tabs are at the bottom as shown in the image to the left.









INSTALLATION INSTRUCTIONS FOR THE RETRO-HPL: (CONTINUED)



STEP 7

Place the Retro-HPL in with the smooth plate from the Retro-HPL behind the 2 tabs as shown in the image to the left.



STEP 8

Hinge the plate up until it locks behind the spring tab. This process is almost identical to replacing the lenses that came with the Source 4 PAR.



STEP 9

Find the HPL Lamp adapter, shown in the image on the left, and locate the fixture connection. This is the smaller green plug.



STEP 10

Place the smaller plug into the back of the Retro-HPL unit through the lamp hole on the back of the fixture, see image on the left. Make sure the green connector seated well in the socket.



STEP 11

Now plug the larger plug into the lamp socket in the cap that was removed in step 3 (or a replacement cap if original cap was determined to be defective) and replace the cap onto the back of the PAR.









INSTALLATION INSTRUCTIONS FOR THE RETRO-HPL: (CONTINUED)



STEP 12

Double check the RETRO-HPL is seated correctly into the PAR and that the lamp cap is securely attached to the back of the PAR.



STEP 13

If you ordered the house light version of the HPL you can skip this section as the lens has already been installed behind a metal retaining ring at the factory. The lens can be swapped out on the house light version if necessary by removing the 4 phillips screws, removing the retaining ring, swapping out the lens, replacing the retaining ring, and then replacing the 4 phillips screws.

For the theatrical version you would choose the lens desired, seat it into place, and use the magnetic retaining ring to hold it into place as shown in the image to the left.



STEP 14

Plug the Source 4 PAR back into its circuit and test to make sure it is responding correctly.

We hope that you enjoy this product as it's intended to provide the same dimming capabilities with significantly less power consumption. Please feel free to give us a call with any questions you may have about your installation.

WARNING: DO NOT USE ETC® LENSES OR GEL FRAME IN THIS UNIT. If the use of gel is required there is a magnetic gel frame that can be purchased separately. Accessories, like open barn doors and top hats, that do not obstruct air flow are acceptable.









INSTALLATION INSTRUCTIONS FOR THE RETRO-HPL: (CONTINUED)

TROUBLESHOOTING:

Should the RETRO-HPL not function please check power, all connections, and the installation instructions to make sure that it was installed correctly. If the unit still does not function we recommend you call us at **888-252-5912** or contact the local dealer who supplied the product to you.

ACCESSORIES:

CantoUSA offers magnetic gel holders and wire screens for use with the RETRO-HPL. Please call your dealer or our sales team at **888-252-5912** should you need to order these.

SPARE PARTS

All components are available as spare parts. We strongly recommend you always use original components as spare parts. Please call our technical team at **888-252-5912** should you need to order and/or replace any parts on your RETRO-HPL unit.

WARRANTY

Our warranty covers all structural and manufacturer defects for three years from the date you purchased this product and 10 years on any LED array. In case of any issues, we strongly recommend you call us at **888-252-5912** or contact the local dealer who supplied the product to you. In any case, please report the serial number of the product when making a warranty claim.

FOR VIDEO INSTRUCTIONS









